NOR_02: Network Data Sending and Receiving

Version	Public version		
Date	01/09/2020		
Status	☐ Draft		




Table of Contents


1.	Intro	oduction	2
	1.1.	Summary	2
	1.2.	Governed / Regulated by	2
	1.3.	Associated Procedures	2
2.	Prod	cedure	3
	2.1.	Preconditions to start	3

Notice

This document is part of the Operational Manual of 4M MC and is governed by Change Control. Any change to this document shall follow the 4M MC Change control procedure. The content of this document might have evolved by the time you read or use this document. Please contact the 4M MC OPSCOM to check that this is the latest version before using this document.

1. Introduction

This procedure describes the sending and reception of the Network Data from Service Provider's local PMB to the other PMBs via the Cloud. At the reception the PMB validates and stores the Network Data in the database.



1.1. Summary

The Network Data are downloaded by each PX and Service Provider from TSO Cloud according to the NOR: Pre Coupling. Service Provider's IT system sends the received Network Data to its own PMB for checks and validations.

Once the Network Data have been validated by the Service Provider's local PMB, Service Provider's PMB sends Network Data to the Cloud. This step is mandatory. Service Provider's operator verifies the sending of Network Data through the PMB interface.

All above steps have to be performed before the Target Time is reached.

Note: No any action is expected from OTE, OKTE, HUPX, OPCOM Local PX IT systems.

The precondition for this procedure is a successful receiving of ATC values by all PXs and SP.

1.2. Governed / Regulated by



1.3. Associated Procedures

In normal situation

- NOR_01: Configuration Synchronization and NOR: Pre Coupling. This previous processes must have been successfully completed.
- NOR_03: Order Data Sending and Receiving. This process is done in parallel with the current process NOR_02.

 NOR_04: Calculation Process. When NOR_02 and NOR_03 are passed successfully, the PMB automatically executes the next step: calculation process.

In backup situation

As soon as an event occurs that prevents the normal performance of the NOR_02 process steps, the operators refer to procedure BUP_02.

2. Procedure

2.1. Preconditions to start

The procedure NOR_01: Configuration Synchronization and NOR: Pre Coupling must have been successfully completed.

