

Pražský výběr – Input List 2025					
No	Patch	Channel	Mic	Stand	
01	A01	Kick In	Beta 91A*		
02	A02	Kick Out	Beta 52A/D6	krátký	
03	A03	Snare 1 Top	e906*/SM57	střední	
04	A04	Snare 1 Btm	e604*		
05	A05	Snare 2	e604*		
06	A06	Hi-Hat R	sE8*		
07	A07	Hi-Hat L	sE8*		
08	A08	Tom 1	e604*		
09	A09	Tom 2	e604*		
10	A10	Tom 3	e604*		
11	A11	Floor Tom	e604*		
12	A12	Overhead L	C451	dlouhý	
13	A13	Overhead R	C451	dlouhý	
14	B01	Perc L	DI*		
15	B02	Perc R	DI*		
16	B03	Perc OH	2x SM57		Y-cable*
17	A14	Bass DI	XLR		
18	A15	Guest **	DI/SM57**	střední	
19	B05	Guitar	XLR*	střední	+Shure klipsna
20	B06	Guitar	XLR*	střední	+Shure klipsna
21	B07	Guitar	XLR*	střední	
22	B08	Guitar	XLR*	střední	
23	B09	Key L	DI*		
24	B10	Key R	DI*		
25	B11	DJ Loop L	DI*		
26	B12	DJ Loop R	DI*		
27	B13	DJ L	XLR*		
28	B14	DJ R	XLR*		
29	B16/D	Voc L	SM58*	dlouhý	+Shure klipsna
30	Direct	Voc C	SM58 wireless	!!!2x dlouhý	SLXD → Axx offset 0dB, mic level 2x klipsna!!! NO SENNHEISER!!!!
31	A16/D	Voc R	SM58	dlouhý	
32	Direct	Voc Guest**	SM58 wireless		SLXD → Axx offset 0dB, mic level NO SENNHEISER!!!!

33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					
46					
47	B04	Click	DI		
48	Direct	TB FOH			
SQ-5 Local Input					
01		Cymatic L	XLR		Bez Rostara
02		Cymatic R	XLR		
03		Cymatic Click	XLR		
04					
05					
06					

Output Patch GX48/16							
No	Channel	Location	Type	No	Channel	Location	Type
01	GTR	DSR	Double wedge	09	Cue IEM L	GX4816	IEM 4L
02	Backup/ Guest	DSC	Single backup Double guest	10	Cue IEM R	GX4816	IEM 4R
03	VOC L	GX4816	IEM 1L	11	Cue LED	GX4816	XLR
04	VOC R	GX4816	IEM 1R	12			
05	Bass	GX4816	IEM 2L	13	Master PA L	GX4816	
06	Perc	GX4816	IEM 2R	14	Master PA R	GX4816	
07	DJ	GX4816	IEM 3L	15	Talk-to-FOH	GX4816	
08	Drums	GX4816	IEM 3R	16	Cue Wedge	GX4816	Single wedge